


Print Number:

Print Date:

Electric Pallet Truck PT16L

PARTS MANUAL

504446020101



Version: V03

Truck Identification Number From:

Parts Manual

PT16L-PM03EN

Please order spare parts from authorized dealers of our company.

In order to avoid wrong delivery, all the orders for spare parts should specify the following items:

- Truck model, identification number and manufacture year.
- Orders for spare parts of mast, hydraulic transmission unit, steering axle, motor, etc. shall indicate the manufacture number of these parts.
- Codes for our company spare parts are shown in the table of parts manual. Please also pay attention to the description of supply status, order quantity, etc. (check the number listed in "Mark" column of the parts manual).

"Mark" Column:

The unmarked indicates the parts are in short supply cycle.

Number 1: supply as package. Indicating these that parts are small parts and seal parts, which are supplied in package unit and in short supply cycle.

Number 2: supply with constraints. Indicating that these spare parts are not in stock and will be prepared for production after receiving the order from customers, which are in long supply cycle.

Number 3: phasing-out supply. Indicating that these parts will be replaced by new parts due to technical improvements and the current stock will not be available when these parts run out. Please check the description of technical improvements notice.

Number 4: supply as assembly. Indicating that these parts are assembly parts defined by manufacture process, which cannot be supplied as a single part.

Number 5: check other tables.


This parts manual is the property of our company and can be shared under the confidential agreement only, our company has the right to claim for compensation of any unauthorized use. Copy without permission is not allowed. Figures in the manual are not limited by the original design. our company reserves the right to improve the products for continuous technology progress.

Table of Contents

Chapter 1: Drive System.....	4
01 Drive Unit (504446013501).....	4
02 Drive Assembly 1.3kW (534746013502)	6
Chapter 2: Hydraulic System.....	8
01 Hydraulic System (504446024001)	8
02 Hydraulic Power Unit (504446024002).....	10
Chapter 3: Truck Frame	12
01 Truck Body (504446021501).....	12
02 Chassis (504446038501).....	14
02 Chassis (504446038501) Continuation1	16
02 Chassis (504446038501) Continuation2.....	18
Chapter 4: Steering System, Braking System, Wheels	20
01 Tiller (504446011001)	20
02 Tiller (535946011002)	22
03 Tiller (566546010002)	24
04 Load Wheel (Tandem) (505646017001).....	26
05 Load Wheel (Single) (505646017002).....	28
06 Caster (504446016501).....	30
Chapter 5: Electrical Parts	32
01 Display Assembly (504746010001).....	32
02 Wire Harness (504446033001)	34
03 Controller (504446033002)	36
04 Wire Harness (504446033003)	38
05 Controller (504446033004).....	40
06 Charger (504446036501).....	42
07 Charger (504446036502).....	44
08 Battery (504446037001).....	46
09 Battery (504446037002).....	48
Chapter 6: Special Parts.....	50
01 Load Backrest (505646040501).....	50
Chapter 7: Others	52
01 Labels and Decals (EU) (504446047001).....	52
02 Labels and Decals (US) (504446047002).....	54
Appendix.....	56
01 Electrical Circuit Diagram (504446045501).....	56
02 Electrical Circuit Diagram (504446045502).....	57
03 Hydraulic Circuit Diagram (504446045503).....	58
04 Consumable Parts List	59


Chapter 1: Drive System

01 Drive Unit (504446013501)



01 Drive Unit (504446013501)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	940700100001	2	Brake	1		
2	910200200060	1	Screw	8		
3	910400500006	1	Spring Washer	9		
4	910400100010	1	Flat Washer	4		
5	910400500010	1	Spring Washer	4		
6	910100300071	1	Bolt	4		
7	504413520001	2	Wheel Mount	1		
8	910400300005	1	Flat Washer	1		
9	910200200058	1	Screw	1		
10	504413520002	2	Bracket	1		
11	910200200075	1	Screw	4		
12	910400500007	1	Spring Washer	4		
13	910600100010	1	Cylindrical Pin	2		
14	940900400002	1	Drive Unit	1		See 534746013502


02 Drive Assembly 1.3kW (534746013502)

02 Drive Assembly 1.3kW (534746013502)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	504498520016	1	Screw	4		
2	504498510005	2	Motor	1		
2.01	504498520011	2	Feather Key	1		
2.02	504498520012	2	Sensor	1		
2.03	504498520013	2	Wiring Board	1		
2.04	504498520010	2	Sensor	1		
3	504498510002	2	Rotary Table Kit	1		
4	504498520005	2	Bolt	5		
5	504498510003	2	Seal Kit	1		
6	940300400005		WheelΦ230x70	1		
7	504498520003	1	Nut	5		

Chapter 2: Hydraulic System

01 Hydraulic System (504446024001)




1= Supply as package. 2= Supply with constraints. 3= Phasing-out supply. 4= Supply as assembly. 5= Check other tables.

01 Hydraulic System (506746024001)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	505638520033	2	Pin	1		
2	940500100019	1	Bushing	2		
3	910401300011	1	Circlip	2		
4	910200200055		Screw	2		
5	910400500006	1	Spring Washer	2		
6	950900100021		Pump Unit	1		See 504446024002
7	504424020005		Hose	1		
8	950401100002		Joint	1		
9	950400400001		Joint	1		
10	504424010001	2	Cylinder	1		
10.01	504498510000	1	Seal Kit	1		
11	910200200075	1	Screw	1		

02 Hydraulic Power Unit (504446024002)




1= Supply as package. 2= Supply with constraints. 3= Phasing-out supply. 4= Supply as assembly. 5= Check other tables.

02 Hydraulic Power Unit (504446024002)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
--	950900100021		Pump Unit	1		
1	504498520017	2	Hoop	1		
2	504498510007	2	Motor	1		
3	504498510011	2	Magnetic Valve	1		
4	504498520018	2	Valve Block	1		
5	504498510012	2	Check Valve	1		
6	504498520019	2	End Cap	2		
7	504498520020	2	O-Ring	1		
8	910800100063	2	O-Ring	1		
9	504498520022	2	Bolt	4		
10	504498510013	2	Gear Pump	1		
11	504498520023	2	Bolt	2		
12	504498520024	2	Oil Tube	1		
13	504498520025	2	Filter	1		
14	504498520026	2	Cables	1		
15	504498510014	2	Switch	1		
16	504498520027	2	Coupling	1		
17	504498510015	2	Overflow Valve	1		
18	504498520028	2	End Cap	1		
19	504498510016	2	Compensation Valve	1		
20	504498520029	2	Cap-Tank	1		
21	504498520030	2	Tank	1		
22	504498510017	2	Carbon Brush	1		

Chapter 3: Truck Frame


01 Truck Body (504446021501)



01 Truck Body (504446021501)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	941100100006	1	Screw	1		
2	940400400003	1	Cage Nut	3		
3	504421520019		Protective Cover	1		
4	910200200035	1	Screw	4		
5	910400500005	1	Spring Washer	6		
6	910400100005	1	Flat Washer	4		
7	504410020001		Protective Cover	1		
8	504410020026		Mounting Plate	1		
9	941100100007	1	Screw	2		
10	504421520020		Protective Cover	1		
11	504410020027		Mounting Plate	1		
12	504421510002	1	Bracket	1		
13	910200200055	1	Screw	4		
14	910400500006	1	Spring Washer	4		
15	504421510001	2	Chassis(EU)	1		
16	505921510002		Pin	2		
17	910200400016	1	Screw	2		
18	910300100007	1	Nut	2		
19	910200200081	1	Screw	2		
20	910200500027		Screw	2		
21	920200300008		Protective cover	1		
22	920200300003		Micro switch	1		
23	910200200033		Screw	2		
24	504421520022		Assembly plate	1		
25	910300100005		Nut	2		
26	920500100001		Horn	1		
27	910200200036		Screw	2		


02 Chassis (504446038501)



02 Chassis (504446038501)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	504438510033	2	Chassis(EU540x1000)	1		
1	504438510035	2	Chassis(EU685x1000)	1		
1	504438510001	2	Chassis(EU540x1150)	1		
1	504438510029	2	Chassis(EU685x1150)	1		
1	504438510028	2	Chassis(EU540x1220)	1		
1	504438510003	2	Chassis(EU685x1220)	1		
1	504438510030	2	Chassis(EU540x1350)	1		
1	504438510032	2	Chassis(EU685x1350)	1		
1	504438510010	2	Chassis(EU540x1400)	1		
1	504438510012	2	Chassis(EU685x1400)	1		
1	504438510013	2	Chassis(EU540x1500)	1		
1	504438510015	2	Chassis(EU685x1500)	1		
1	504438510016	2	Chassis(EU540x1600)	1		
1	504438510018	2	Chassis(EU685x1600)	1		
1	504438510008	2	Chassis(EU540x1800)	1		
1	504438510021	2	Chassis(EU685x1800)	1		
1	504438510022	2	Chassis(EU540x2000)	1		
1	504438510024	2	Chassis(EU685x2000)	1		
1	504438510025	2	Chassis(EU540x2400)	1		
1	504438510019	2	Chassis(EU685x2400)	1		
2	910200400016	1	Screw	3		
3	505638520031		Fixing Plate	1		
4	505638510001		Rise Arm	1		540
4	505638510007		Rise Arm	1		685
5	940500100027		Bushing	2		
6	940500100019		Bushing	2		
7	940500100032		Bushing	2		
8	505638520034		Pin	2		
9	910401700005	1	Circlip	2		
10	505638510003		Pin	1		


02 Chassis (504446038501) Continuation1



02 Chassis (504446038501) Continuation1


No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
11	505638520037		Axle	2		
12	910600500004		Spring Pin	2		
13	504498510019	2	Push Rod Kit(1000)	2		1000
13	504498510008	2	Push Rod Kit(1150)	2		1150
13	504498510009	2	Push Rod Kit(1220)	2		1220
13	504498510020	2	Push Rod Kit(1350)	2		1350
13	504498510021	2	Push Rod Kit(1400)	2		1400
13	504498510022	2	Push Rod Kit(1500)	2		1500
13	504498510023	2	Push Rod Kit(1600)	2		1600
13	504498510024	2	Push Rod Kit(1800)	2		1800
13	504498510025	2	Push Rod Kit(2000)	2		2000
13	504498510026	2	Push Rod Kit(2400)	2		2400
13.01	505638520035		Push Rod Fork	2		
13.02	910300400010	1	Nut	4		
13.03	504438510034	2	Push Rod (1000)	2		1000
13.03	504438510002	2	Push Rod (1150)	2		1150
13.03	504438510004	2	Push Rod (1220)	2		1220
13.03	504438510031	2	Push Rod (1350)	2		1350
13.03	504438510011	2	Push Rod (1400)	2		1400
13.03	504438510014	2	Push Rod (1500)	2		1500
13.03	504438510017	2	Push Rod (1600)	2		1600
13.03	504438510009	2	Push Rod (1800)	2		1800
13.03	504438510023	2	Push Rod (2000)	2		2000
13.03	504438510020	2	Push Rod (2400)	2		2400
13.04	940500100012		Bushing	4		
13.05	911200100001	1	Oil Cup	2		
14	910200200056	1	Screw	2		
15	910400500006	1	Spring Washer	2		
16	504438520017		Stop Plate	2		
17	505921020007		Sealing Strip	1		

02 Chassis (504446038501) Continuation2



02 Chassis (504446038501) Continuation2


No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
18	504421010001		Cell Cover	1		
19	505621020004		Crash Pad	3		

Chapter 4: Steering System, Braking System, Wheels**01 Tiller (504446011001)**

01 Tiller (504446011001)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	922100100001		Tiller	1		See 535946011002
1	922100100099		Tiller	1		See 566546010002
2	910200200057	1	Screw	2		
3	534733010001		Wire Harness	1		
4	504411010001		Tiller	1		
5	504411020011		Axle	1		
6	910600400009	1	Spring Pin	1		
7	502311020009		Close Plate	1		
8	941100400001	1	Screw	1		
9	504411010004		Air Spring	1		
10	910100300024	1	Bolt	1		
11	504411020013	1	Spacer Bush	1		
12	910200500015	1	Screw	2		
13	505633510002		Proximity Switch	1		
14	910200200014	1	Screw	2		
15	504411020009		Baseboard	1		


02 Tiller (535946011002)



535946011002

02 Tiller (535946011002)


No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
--	922100100001		Tiller	1		
1	505698520008		Screw	2		
2	505698520009		Washer	2		
3	505698520001		Traction lever	1		
4	505698520004		Sleeve	2		
5	505698520027		Torsional Spring	1		
6	505698520014		Handle Cap	1		
7	505698520016		Button cap	1		
8	505698520005		Magnet	4		
9	505698520021		Button Cap	1		
10	505698520002		Horn Button	1		
11	505698520003		Spring	5		
12	505698520022		Button Cap	1		
13	505698520018		Torsional Spring	2		
14	505698520017		Fixing Base	2		
15	505698520028		circuit Board	1		
16	505698520015		Handle Cap	1		
17	505698520007		Screw	3		
18	505698520020		Button Cap	1		
19	505698520019		Pedestal	1		
20	505698520006		Spring	4		
21	505698520026		Torsional Spring	1		
22	505698520012		Clamp	1		
23	505698520023		Screw	1		
24	505698520024		Light	1		
25	505698520025		Lamp Holder	1		
26	505698520011		Axle-Traction lever	1		
27	505698520010		Traction lever	1		
28	505698520013		Sensor	2		

03 Tiller (566546010002)

03 Tiller (566546010002)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	505698520016		Button cap	1		
2	505698520005		Magnet	4		
3	505698520018		Torsional Spring	2		
4	505698520008		Screw	2		
5	505698520001		Traction lever	1		
6	505698520004		Sleeve	2		
7	505698520027		Torsional Spring	1		
8	505698520009		Washer	2		
9	505698520003		Spring	5		
10	505698520099		Handle Cap	1		
11	505698520006		Spring	4		
12	505698520020		Button Cap-	1		
13	505698520100		Pedestal	1		
14	505698520012		Clamp	1		
15	505698520023		Screw	1		
16	505698520102		Magnet holder	2		
17	505698520024		Light	1		
18	505698520025		Lamp Holder	1		
19	505698520026		Torsional Spring	1		
20	505698520011		Axle-Traction lever	1		
21	505698520010		Traction lever	1		
22	505698520007		Screw	3		
23	505698520015		Handle Cap	1		
24	505698520013		Sensor	2		
25	505698520101		circuit Board	1		
26	505698520002		Horn Button	1		
27	505698520017		Fixing Base	2		
28	505698520021		Button Cap	1		
29	505698520022		Button Cap	1		


04 Load Wheel (Tandem) (505646017001)



1= Supply as package. 2= Supply with constraints. 3= Phasing-out supply. 4= Supply as assembly. 5= Check other tables.

04 Load Wheel (Tandem) (505646017001)


No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	910600400027	1	Spring Pin	8		
2	505638520038		Pin	2		
3	911200100001		Oil Cup	2		
4	940500100012		Bushing	4		
5	505638520036		Riser	2		
6	940500200003		Bushing	2		
7	502398510003		Pulley components	2		
7.01	910100100035	1	Bolt	2		
7.02	505638520039		Running Pulley	2		
7.03	910300500005	1	Nut	2		
8	505617020001		Plate	4		
9	505617020000		Axle	4		
10	505698510003		Wheel	4		
10.01	940300300010		WheelΦ84x84	4		
10.02	910700200019		Bearing	8		

05 Load Wheel (Single) (505646017002)

05 Load Wheel (Single) (505646017002)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	910600400027	1	Spring Pin	4		
2	505638520038		Pin	2		
3	911200100001		Oil Cup	2		
4	940500100012		Bushing	4		
5	505638520036		Riser	2		
6	505698510004		Wheel	2		
6.01	940300300006		WheelΦ82x110	2		
6.02	910700200019		Bearing	4		
7	502398510003		Pulley components	2		
7.01	910100100035	1	Bolt	2		
7.02	505638520039		Running Pulley	2		
7.03	910300500005	1	Nut	2		
8	505617020002		Axle	2		
9	910600400030	1	Spring Pin	4		

06 Caster (504446016501)




06 Caster (504446016501)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
--	504416510001		Caster Assembly	1		
1	941100300001	1	Screw	1		
2	910600100004	1	Cylindrical Pin	1		
3	505616520007	1	Retaining Ring	1		
4	505616520014		Pad	1		
5	504416510002	2	Plate	1		
6	910700500002		Bearing	1		
7	910401400016	1	Circlip	1		
8	505616520000		Spring	1		
9	910300500006	1	Nut	1		
10	505616520013	1	Bushing	1		
11	910300500005	1	Nut	1		
12	941100200002	1	Bolt	1		
13	940400500006	1	Spring	1		
14	505616510003	2	Whirling Arm	1		
15	940500100002		Bushing	2		
16	910100100038	1	Bolt	1		
17	505698510000		Wheel	1		
17.01	910700200019		Bearing	2		
17.02	940300300018		WheelΦ100x40	1		
18	505616520012	1	Check Ring	2		
19	505616520011		Dust Cap	2		


Chapter 5: Electrical Parts

01 Display Assembly (504746010001)




01 Display Assembly (504746010001)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	910200500016		Screw	2		
2	920200100001		Emergency Button	1		
2.01	920200100008		Emergency Button	1		
2.02	505698520030		Proximity Switch	1		
3	910300100002		Nut	2		
4	920200200002		Key Switch	1		
5	505634010000		Key Switch	1		
5	505634010001		Key Switch	1		
6	921100100012		Display	1		
6	921100100116		Display	1		curtis
7	910200200023		Screw	2		
8	910400500004		Spring Washer	2		
9	504421520023		Bracket	1		
10	910200200014		Screw	4		
11	910400500003		Spring Washer	10		
12	921300300005		Holder	5		
13	910400100003		Flat Washer	3		
14	910200500022		Screw	6		
15	921300300010		Connector Holder	3		
16	504421520024		Plate	1		

02 Wire Harness (504446033001)

02 Wire Harness (504446033001)


No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	504433010000		Wire Harness	1		
1	504433010012		Wire Harness	1		Li battery
2	504433010003		Cable	1		
3	504433010004		Cable	1		
4	504433010005		Cable	1		
5	504433010006		Cable	1		
6	504433010007		Cable	1		
7	504433010008		Wire Harness	1		
7	504433010013		Wire Harness	1		Li battery
8	504433010009		Cable	1		
9	504433010010		Cable	1		

03 Controller (504446033002)

03 Controller (504446033002)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	504421520025		Mounting Plate	1		
2	504433020000		Plate	1		
3	921400100025		Controller	1		
4	920800100001		Relay	1		
5	920100400006		Fuse Holder	1		
6	920100200002		Fuse	1		
7	920100400002		Fuse Holder	1		
8	920100100007		Fuse	1		
9	910400100004		Flat Washer	1		
10	920700100004		Contactactor	1		
11	921300400001		Holder	1		
12	920100400001		Fuse Holder	1		
13	921300300001		Holder	1		
14	504433020001		Copper Busbar	1		
15	505633020002		Copper Busbar	1		
16	505633020003		Copper Busbar	1		


04 Wire Harness (504446033003)



04 Wire Harness (504446033003)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	504733010005		Wire Harness (AC-F2A)	1		
2	504533010002		Cable-U-10-6-6-650	1		
3	504533010003		Cable-V-10-6-6-680	1		
4	504533010004		Cable-W-10-6-6-710	1		
5	504433010007		Cable-E2-10-6-8-1050	1		
6	504433010006		Cable-FP-10-8-8-1060	1		
7	504733010010		Wire Harness (AC-F2A)	1		
8	504433010009		Cable-FU+-8-8-930	1		
9	920100300001		Fuse 0.5A	1		


05Controller (504446033004)



1= Supply as package. 2= Supply with constraints. 3= Phasing-out supply. 4= Supply as assembly. 5= Check other tables.


05 Controller (504446033004)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	505633020004		Plate	1		
2	921400100164		Controller	1		
3	505633020007		Copper Busbar	1		
4	920700100004		Contactactor	1		
5	921300400001		Holder	1		
6	504733020001		Copper Busbar			
7	920800100001		Relay	1		
8	505633020002		Copper Busbar	1		
9	920100100007		Fuse 150A	1		
10	505633020003		Copper Busbar	1		
11	920100400002		Fuse Holder	1		
12	920100100004		Fuse 80A	1		
13	921300300001		Holder	1		
14	920100400006		Fuse Holder	1		
15	920100200002		Fuse 10A	1		
16	920100400001		Fuse Holder	1		
17	921300200012		Cable fastener	1		
18	504421520025		Mounting Plate	1		

06 Charger (504446036501)**504446036501**


06 Charger (504446036501)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	921000200014		Charger24V25A(Aisa-ENG)	1		
1	921000200015		Charger24V25A(EU)	1		
1	921000200016		Charger24V25A(AUS)	1		
1	921000200017		Charger24V25A(ENG)	1		
1	921000200018		Charger24V25A(USA)	1		
1	921000200364		Charger24V25A (ISR)	1		
1	921000200442		Charger24V25A(ARG)	1		
1	921000200006		Charger24V30A(USA)	1		
1	921000200002		Charger24V30A(Aisa-ENG)	1		

07 Charger (504446036502)


07 Charger (504446036502)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	921000200524		Charger 24V60A (EU)	1		Li battery
1	921000200525		Charger 24V60A (ENG)	1		Li battery
1	921000200526		Charger 24V60A (AUS)	1		Li battery
1	921000200527		Charger 24V60A (ISR)	1		Li battery
1	921000200528		Charger 24V60A (ARG)	1		Li battery
1	921000200529		Charger 24V60A (ZA)	1		Li battery
1	921000200530		Charger 24V60A (US)	1		Li battery
1	921000200631		Charger 24V60A (TH)	1		Li battery
1	921000200690		Charger 24V60A (US- three	1		Li battery
1	921000200663		Charger 24V60A (ZA)	1		Li battery
1	921000200523		Charger 24V60A (Asia-EN)	1		Li battery
1	921000200724		Charger ADY24V60A (BRA)	1		Li battery
1	921000200723		Charger ADY24V50A (US)	1		Li battery

08 Battery (504446037001)

08 Battery (504446037001)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	504437010001		Battery24V160Ah	1		
1	504437010002		Battery24V160Ah(welded)	1		
1	920600100500		Battery24V160Ah	1		EN1175
1	920600100579		Battery24V160Ah(welded)	1		EN1175


09 Battery (504446037002)

09 Battery (504446037002)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	920600100304		Li-Battery24V100Ah	1		
1	920600100306		Li-Battery 24V150Ah	1		

Chapter 6: Special Parts

01 Load Backrest (505646040501)




01 Load Backrest (505646040501)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	505640510001		Load Backrest	1		
2	505640520004		Mounting Plate	2		
3	910200400036	1	Screw	4		

Chapter 7: Others


01 Labels and Decals (EU) (504446047001)



01 Labels and Decals (EU) (504446047001)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	941200100003		Label	1		
2	504447020001		Truck data plate	1		
3	941200200021		Label	1		
4	941200300001		Label	1		
5	941200300002		Label	1		
6	941200300003		Label	2		

02 Labels and Decals (US) (504446047002)




1= Supply as package. 2= Supply with constraints. 3= Phasing-out supply. 4= Supply as assembly. 5= Check other tables.

02 Labels and Decals (US) (504446047002)

No.	Item Code	Mark	Item Description	Qty.	Substitute	Note
1	941200100013		Label	1		
2	941200100011		Label	1		
3	941200100012		Label	1		
4	941200300002		Label	1		
5	941200100010		Label	1		
6	941200100009		Label	1		
7	941200300003		Label	1		
8	941200200036		Label	1		
9	504447020002		Truck data plate	1		
10	941200300001		Label	2		


Appendix

01 Electrical Circuit Diagram (504446045501)




1= Supply as package. 2= Supply with constraints. 3= Phasing-out supply. 4= Supply as assembly. 5= Check other tables.

02 Electrical Circuit Diagram (504446045502)



1= Supply as package. 2= Supply with constraints. 3= Phasing-out supply. 4= Supply as assembly. 5= Check other tables.

03 Hydraulic Circuit Diagram (504446045503)



04 Consumable Parts List

No.	Item Code	Item Description	Qty.	Chapter/ Section/ Number
1	504498510000	Seal Kit	1	Chapter 2/01/13.01
2	940500100027	Bushing	2	Chapter 3/02/5
3	940500100019	Bushing	2	Chapter 3/02/6
4	940500100032	Bushing	2	Chapter 3/02/7
5	940500100012	Bushing	12	Chapter 4/02/10.04 Chapter 4/03/4
5	940500100012	Bushing		Chapter 4/04/4
6	911200100001	Oil Cup	2	Chapter 4/02/13.05
7	911200100001	Oil Cup	2	Chapter 4/03/3
8	940500200003	Bushing	2	Chapter 4/03/6
9	911200100001	Oil Cup	2	Chapter 4/04/3
10	910700500002	Bearing	1	Chapter 4/05/6
11	940500100002	Bushing	2	Chapter 4/05/15
12	910700200019	Bearing	2	Chapter 4/05/17.01
13	920100200002	Fuse	1	Chapter 5/03/6
14	920100100007	Fuse	1	Chapter 5/03/8